

# teleskopy.pl



Heating band intended for cooled ZWO ASI cameras. Prevents the dew from being deposited on the front of the camera, die and window inlet. The set includes a heating strap, power cord, two spacers and a clamping clamp. The thickness of the heating strap is 0.2 - 0.3 mm. The power cord can be connected in series with the power supply of the camera's cooling system. The two spacers are 0.3 mm and 0.5 mm thick, they are used with the simultaneous use of the EFW filter wheel. The recommended current is 0.35 A at 12 V, which provides a heating power of 4.2 watts. When using the power supply at the same time as the cooling system and heater, make sure that the current does not exceed the recommended one. Warranty 24 months HOW TO USE A BAND? remove the adhesive tape stick the heating strap on the front of the camera, making sure that the black power cord is located next to the camera's DC power plug

---

on the back of the camera body / attach the black cable clamp to the camera body plug in the power cord; the heating band is ready for use and will prevent the dew from settling on the essential elements of the camera