

teleskopy.pl



Cleaning pen LENS PEN type - a dual-purpose device, which on the one hand is equipped with a fine brush to remove dust and dirt, on the other hand has two replaceable, flexible cleaning tips. The tips are made in a technology that allows cleaning the surface of dirt such as fingerprints and greasy stains without the use of detergents. They do not get wet and do not dry out. Two ends: round and triangular allow you to clean surfaces of various shapes.